

Oxtopus 

User Manual

Installation – Router setting

This manual describe the wiring and setting to operate the multi-protocol Oxtopus router EIA-709 and Modbus

This manual is organized in different chapter. Each can be read independently. The annexes are supplements to use routers in their environment.

OCCITALINE

13 Rue Antoine Lavoisier
31830 Plaisance-Du-Touch
France
+33(0)5 34 28 12 24
support@occitaline.com

Terminology

| | |
|-----------------|---|
| Lon | Name usually given to the protocol or component working in EIA-709.1. |
| LonWorks® | Name given to the communication system developed by Echelon Corp under denomination EIA-709.1 or ISO-14908.1. |
| Modbus | Protocol used in building automation and industry for exchange data between two devices. |
| TP / FT10 | Name given to the medium "Twisted Pair Free Topology" and operating at 78125 bits / s. |
| EIA-709.1 | Generic identification for the protocol used between nodes on a network. |
| Node | Common name given to device exchanging data with protocol EIA-709.1. |
| EIA-852 | Generic name for transport protocol EIA-709.1 over IP. |
| Config Server | Virtual administrator for "IP Channel" (EIA-852). |
| Channel IP | Virtual LAN that will be seen in the administrative tools as a communication medium just like a twisted pair. |
| Modbus | Modbus frames NAT routing function for address translation. |
| Echelon | Company that created the LonWorks® technology and has deposited the brand Echelon, LonWorks, LNS®, Neuron Chip®. |
| BACnet® | Protocol defined by ASHRAE SPC 135 and ISO-16484.5 normalised. This protocol includes power full objects for the Building Automation. |
| BACnet Object | An object is made by several properties representing the itself object values and exposed onto the network. |
| BACnet Property | BACnet properties are the values that make up a BACnet Object. |
| Network Number | It's a unique number per channel. Each router has both network number and port : IP and MS/TP Port. |

Contents

| | | |
|------------|---|-----------|
| 1 | INTRODUCTION | 6 |
| 1.2 | RANGE OF OXTOPUS ROUTERS | 7 |
| 1.3 | ETHERNET CONNECTION | 9 |
| 1.4 | WIFI CONNECTION – ETHERNET | 9 |
| 1.5 | AUTOMATION PROTOCOLS SUPPORTED | 10 |
| 1.5.1 | ROUTER EIA-709.1 | 10 |
| 1.5.2 | BACNET IP/MSTP ROUTER | 10 |
| 1.5.3 | NAT MODBUS ROUTER | 10 |
| 1.5.4 | LON SCHEDULER | 11 |
| 1.6 | OTHER PROTOCOLS SUPPORTED | 12 |
| 1.6.1 | EIA-852 DEVICE | 12 |
| 1.6.2 | EIA-852 CONFIG SERVER | 12 |
| 1.6.3 | WEB | 13 |
| 1.6.4 | DISK SPACE EMBEDDED IN FTP | 13 |
| 2 | CONNECTION AND MATERIAL | 14 |
| 2.1 | ETHERNET | 15 |
| 2.2 | WIFI | 15 |
| 2.3 | POWER | 15 |
| 2.4 | WIRING | 15 |
| 2.5 | WIRED NETWORK EIA-709.1 / EIA-485 MODBUS | 16 |
| 2.6 | LED SIGNALIZATION | 17 |
| 2.6.1 | POWER LED | 17 |
| 2.6.2 | WIFI LED | 17 |
| 2.6.3 | IP1/IP2 LED | 17 |
| 2.6.4 | LED ACTIVITY (« ACT. ») | 17 |
| 2.6.5 | LED Z | 18 |
| 2.7 | SCREEN | 18 |
| 3 | EASY AND FAST SETTING | 20 |
| 3.1 | WIZARD FOR CONFIGURATION | 21 |
| 3.2 | STARTING WIZARD ON HOME PAGE | 21 |
| 3.3 | LOGIN PAGE | 22 |
| 3.4 | NAME OF ROUTER | 22 |
| 3.5 | IP ADDRESS | 22 |
| 3.6 | WIFI CONFIGURATION | 23 |
| 3.7 | EIA-852 CONFIGURATION | 24 |
| 3.8 | MODBUS CONFIGURATION | 26 |
| 3.9 | CONFIRM AND REBOOT | 27 |
| 4 | DETAILS SETTINGS | 28 |

| | | |
|-------------|--|-----------|
| 4.1 | RESIZABLE PAGE TO THE SCREEN DEVICE | 29 |
| 4.2 | HOME PAGE | 30 |
| 4.2.1 | DEVICE INFO | 31 |
| 4.2.2 | ETHERNET CHAPTER | 32 |
| 4.2.3 | PORTS CHAPTER | 33 |
| 4.3 | MENUS | 34 |
| 4.4 | LOGIN PAGE | 35 |
| 4.5 | USER MODIFICATION ACCOUNT | 35 |
| 4.6 | REBOOT PAGE | 36 |
| 4.7 | SYSTEM CONFIGURATION | 37 |
| 4.8 | CONFIGURATION | 37 |
| 4.9 | PORT EIA-709 | 38 |
| 4.10 | PORT EIA-852 CLIENT | 38 |
| 4.11 | THE CONFIG SERVER | 39 |
| 4.12 | CHANNEL LIST | 40 |
| 4.13 | MODBUS SERVER STAT EIA-709 CONFIGURATION | 41 |
| 4.14 | MODBUS SERIAL PORTS CONFIGURATION | 41 |
| 4.15 | MODBUS NAT ROUTER CONFIGURATION | 42 |
| 4.16 | BACNET CONFIGURATION | 43 |
| 4.16.1 | DEVICE AND BACNET IP | 43 |
| 4.16.2 | MSTP PORTS | 44 |
| 5 | LON SCHEDULER | 45 |
| 5.1 | OVERVIEW | 46 |
| 5.2 | THE HOME PAGE | 46 |
| 5.3 | CONFIGURATION | 47 |
| 5.3.1 | SCHEDULER MENU | 47 |
| 5.3.2 | LONWORKS CONFIGURATION | 48 |
| 5.3.3 | BACNET CONFIGURATION | 49 |
| 5.3.4 | LON NODE INSTALLATION | 51 |
| 5.3.5 | INSTALLING TEMPLATE FILES | 51 |
| 5.3.6 | ADDING THE LON SCHEDULER TO AN OXTOPUS CONFIG SERVER | 52 |
| 5.3.7 | INSTALLATION IN AN LNS BASE WITH NL220 | 52 |
| 5.3.8 | BINDING | 54 |
| 6 | CONFIGURATION VIA USB | 56 |
| 6.1 | GENERAL INFORMATION | 57 |
| 6.2 | DEFAULT IP ADDRESS | 57 |
| 6.3 | RESTARTING | 58 |
| 7 | SMART CHANNEL USAGE | 60 |
| 7.1 | PREAMBLE | 61 |
| 7.2 | MAIN CHANNEL MODIFICATION | 61 |

| | | |
|------------|--|-----------|
| 8 | APPENDIX | 66 |
| 8.1 | RESOURCES INSTALLATION FOR NLSMARTCHANNEL | 67 |
| 8.2 | USB DRIVER INSTALLATION | 68 |
| 8.2.1 | ON WINDOWS 8 | 68 |
| 8.2.2 | ON WINDOWS XP / 7 | 68 |
| 8.3 | TERMINAL INSTALLATION (TERA TERM) | 69 |

1 Introduction

1.2 Range of Oxtopus routers

Oxtopus routers are available in several product references.

| Part-Number | | Sched | Port Ethernet | Wifi | Port TP/FT10 EIA-709 | Port EIA-485 Modbus | Port BACnet MS/TP |
|------------------------|------------------|-------|---------------|------|----------------------|---------------------|-------------------|
| LonWorks Only | Ox-1Lo | No | 2 en Switch | No | 1 | | |
| | Ox-1Lo-Sc | Yes | 2 en Switch | No | 1 | | |
| | Ox-1Lo-Wi | No | 2 en Switch | Yes | 1 | | |
| | Ox-1Lo-Sc-Wi | Yes | 2 en Switch | Yes | 1 | | |
| | Ox-2Lo | No | 2 en Switch | No | 2 | | |
| | Ox-2Lo-Sc | Yes | 2 en Switch | No | 2 | | |
| | Ox-2Lo-Wi | No | 2 en Switch | Yes | 2 | | |
| | Ox-2Lo-Sc-Wi | No | 2 en Switch | Yes | 2 | | |
| | Ox-3Lo | No | 2 en Switch | No | 3 | | |
| | Ox-3Lo-Sc | Yes | 2 en Switch | No | 3 | | |
| | Ox-3Lo-Wi | No | 2 en Switch | Yes | 3 | | |
| | Ox-3Lo-Sc-Wi | Yes | 2 en Switch | Yes | 3 | | |
| | Ox-4Lo | No | 2 en Switch | No | 4 | | |
| | Ox-4Lo-Sc | Yes | 2 en Switch | No | 4 | | |
| | Ox-4Lo-Wi | No | 2 en Switch | Yes | 4 | | |
| | Ox-4Lo-Sc-Wi | Yes | 2 en Switch | Yes | 4 | | |
| Modbus Only | Ox-1Mo | n/a | 2 en Switch | No | | 1 | |
| | Ox-1Mo-Wi | n/a | 2 en Switch | Yes | | 1 | |
| | Ox-2Mo | n/a | 2 en Switch | No | | 2 | |
| | Ox-2Mo-Wi | n/a | 2 en Switch | Yes | | 2 | |
| | Ox-3Mo | n/a | 2 en Switch | No | | 3 | |
| | Ox-3Mo-Wi | n/a | 2 en Switch | Yes | | 3 | |
| | Ox-4Mo | n/a | 2 en Switch | No | | 4 | |
| | Ox-4Mo-Wi | n/a | 2 en Switch | Yes | | 4 | |
| Mixed EIA-709 + Modbus | Ox-1Lo-1Mo | No | 2 en Switch | No | 1 | 1 | |
| | Ox-1Lo-1Mo-Sc | Yes | 2 en Switch | No | 1 | 1 | |
| | Ox-1Lo-1Mo-Wi | No | 2 en Switch | Yes | 1 | 1 | |
| | Ox-1Lo-1Mo-Sc-Wi | Yes | 2 en Switch | Yes | 1 | 1 | |
| | Ox-1Lo-2Mo | No | 2 en Switch | No | 1 | 2 | |
| | Ox-1Lo-2Mo-Sc | Yes | 2 en Switch | No | 1 | 2 | |
| | Ox-1Lo-2Mo-Wi | No | 2 en Switch | Yes | 1 | 2 | |
| | Ox-1Lo-2Mo-Sc-Wi | Yes | 2 en Switch | Yes | 1 | 2 | |
| | Ox-1Lo-3Mo | No | 2 en Switch | No | 1 | 3 | |
| | Ox-1Lo-3Mo-Sc | Yes | 2 en Switch | No | 1 | 3 | |
| | Ox-1Lo-3Mo-Wi | No | 2 en Switch | Yes | 1 | 3 | |
| | Ox-1Lo-3Mo-Sc-Wi | Yes | 2 en Switch | Yes | 1 | 3 | |
| | Ox-2Lo-1Mo | No | 2 en Switch | No | 2 | 1 | |
| | Ox-2Lo-1Mo-Sc | Yes | 2 en Switch | No | 2 | 1 | |
| | Ox-2Lo-1Mo-Wi | No | 2 en Switch | Yes | 2 | 1 | |
| | Ox-2Lo-1Mo-Sc-Wi | Yes | 2 en Switch | Yes | 2 | 1 | |
| | Ox-2Lo-2Mo | No | 2 en Switch | No | 2 | 2 | |
| | Ox-2Lo-2Mo-Sc | Yes | 2 en Switch | No | 2 | 2 | |
| | Ox-2Lo-2Mo-Wi | No | 2 en Switch | Yes | 2 | 2 | |
| | Ox-2Lo-2Mo-Sc-Wi | Yes | 2 en Switch | Yes | 2 | 2 | |

| | | | | | | | |
|------------------------|------------------|-----|-------------|-----|---|---|---|
| | Ox-3Lo-1Mo | No | 2 en Switch | No | 3 | 1 | |
| | Ox-3Lo-1Mo-Sc | Yes | 2 en Switch | No | 3 | 1 | |
| | Ox-3Lo-1Mo-Wi | No | 2 en Switch | Yes | 3 | 1 | |
| | Ox-3Lo-1Mo-Sc-Wi | Yes | 2 en Switch | Yes | 3 | 1 | |
| BACnet® Only | Ox-1Ba | No | 2 en Switch | No | | | 1 |
| | Ox-1Ba-Wi | No | 2 en Switch | Yes | | | 1 |
| | Ox-2Ba | No | 2 en Switch | No | | | 2 |
| | Ox-2Ba-Wi | No | 2 en Switch | Yes | | | 2 |
| | Ox-3Ba | No | 2 en Switch | No | | | 3 |
| | Ox-3Ba-Wi | No | 2 en Switch | Yes | | | 3 |
| | Ox-4Ba | No | 2 en Switch | No | | | 4 |
| | Ox-4Ba-1Wi | No | 2 en Switch | Yes | | | 4 |
| Mixed BACnet® + Modbus | Ox-1Ba-1Mo | No | 2 en Switch | No | | 1 | 1 |
| | Ox-1Ba-1Mo-Wi | No | 2 en Switch | Yes | | 1 | 1 |
| | Ox-1Ba-2Mo | No | 2 en Switch | No | | 2 | 1 |
| | Ox-1Ba-2Mo-Wi | No | 2 en Switch | Yes | | 2 | 1 |
| | Ox-1Ba-3Mo | No | 2 en Switch | No | | 3 | 1 |
| | Ox-1Ba-3Mo-Wi | No | 2 en Switch | Yes | | 3 | 1 |
| | Ox-2Ba-1Mo | No | 2 en Switch | No | | 1 | 2 |
| | Ox-2Ba-1Mo-Wi | No | 2 en Switch | Yes | | 1 | 2 |
| | Ox-2Ba-2Mo | No | 2 en Switch | No | | 2 | 2 |
| | Ox-2Ba-2Mo-Wi | No | 2 en Switch | Yes | | 2 | 2 |
| | Ox-3Ba-1Mo | No | 2 en Switch | No | | 1 | 3 |
| | Ox-3Ba-1Mo-Wi | No | 2 en Switch | Yes | | 1 | 3 |



« -Sc » for « **LON Scheduler** ». Regardless of the product reference containing the LonWorks protocol you can add the LON Scheduler. The operation of the scheduler is described in 1.5.4, its configuration is described in chapter5.



Figure 1
Front view of Oxtopus router

1.3 Ethernet connection

All references are equipped with two RJ45 connectors. Communication can be done independently on both sides with network.



Figure 2
Ethernet Connectors Eth0 and Eth1



The two RJ45 Ethernet connectors are configured in factory as Ethernet switch. The main connector is the left ETH0. The Computer must be primarily connected to this port.

In this configuration, the router has only one IP address for all its functions.

1.4 Wifi Connection – Ethernet

The Wifi option proposed in Oxtopus references allows access to Ethernet RJ45.




Figure 3
Architecture Ethernet IP

A computer can connect over WiFi Oxtopus to reach other Oxtopus or other equipment as the LNS server.

If a DHCP server provides an IP address on Ethernet, the computer do not need a fixed IP address, its Wi-Fi connection will assign a network address automatically.

1.5 Automation protocols supported

The EIA-709.1 and Modbus protocols are supported on Oxtopus router and run on IP separately.

1.5.1 Router EIA-709.1

In Oxtopus routers, the EIA-709.1 protocol is available either on twisted pair or over IP. In order to pass from one media to another, it is implemented in a router function. This conforms to the EIA-709.1 protocol and ensures the traffic filtering.




Figure 4
Architecture of Oxtopus router

To connect 2 media, a simple router is enough. To connect more than 2 medias a Virtual Media is introduced into the router to follow the installation and operate procedures of the EIA-709.1 networks.

1.5.2 BACnet IP/MSTP router

Oxtopus Ox-xBa routers allow you to connect your BACnet / IP network to your BACnet MS / TP network. The routing function ensures the passage of a media to another while filtering the traffic.

Up to four opto-isolated MSTP ports are available on a router.

1.5.3 NAT Modbus router

The Modbus protocol cannot be a router function. It was implemented a frame redirection by changing the slave address. Hence the term NAT Router (Address Translation Router). Depending on the number of EIA-485 Modbus port available on the reference, Modbus master address requests on IP, the request will be redirected to the desired port with a new slave address.

Each EIA-485 port can only support 31 Modbus slaves. The Modbus address space is limited to 247 members. Within the maximum terms it is possible to send $31 * 4 = 124$ Modbus slaves on EIA-485.

Configuration example:

| Slave source address | Port EIA-485 | Slave destination address |
|----------------------|--------------|---------------------------|
| 10 | Port 3 | 1 |
| 11 | Port 3 | 2 |
| 20 | Port 4 | 1 |
| 21 | Port 4 | 2 |

1.5.4 LON Scheduler

The LonWorks scheduler associates two BACnet schedulers to a LON / IP node, both integrated into the Oxtopus router. The configuration interface via the embedded website allows the user to define, for a given value of "Present_Value", the values of the set of associated variables. For each event defined in the BACnet Scheduler the LonWorks variables will be propagated.




Figure 5 LON Scheduler architecture

On the LonWorks side, there are 5 functional blocks. Each function block has 10 network variables, 5 nvi and 5 nvo of type:

- SNVT_temp_p
- SNVT_switch
- SNVT_occupancy
- SNVT_setting
- SNVT_lev_percent

Changing a nvi variable will propagate the value to the nvo of the same type. If the BACnet scheduler changes enumeration value, the 5 variables will change value according to the associated table.




Figure 6 LON Scheduler node



The values of the nvo can be fixed either by the modification of the nvi of the same type, or by the scheduler via what we call the "Internal dataPoint". Any changes are directly applied to the nvo.

The value of the nvo is always equal to the last updated input value

1.6 Other protocols supported

1.6.1 EIA-852 Device

This protocol is transparent for the installer and operator of the router. It is used for exchanges between members of a Channel IP.

1.6.2 EIA-852 Config Server

It is the virtual administrator of a Channel IP. All nodes or routers members of this channel are declared in a list ("channel list") and may share data.

If a member is forgotten it cannot share with others.



The « Config Server » router must be declared in the channel list as member.



A router cannot belong on two channel lists member.

1.6.3 Web

An embedded Web server provides the router setup and provides a view of the general state of the router. It is accessible via its IP address with a browser like Firefox, Chrome or Internet Explorer. You can also access via WiFi with a tablet or smartphone. Web pages are automatically resized according to your device.

The configuration pages are protected by password.

Login : « **admin** », Password: « **oxpass** »

1.6.4 Disk space embedded in FTP

A user disk space is available to store your files or documentation. This space is limited access via FTP with login and password.

Login : « **ftp** », Password: « **ftp** ».

2 Connection and Material

2.1 Ethernet

The cables used should not exceed 90 meters. The left connector Eth0 must be privileged.

The default address is 192.168.1.254.

2.2 Wifi

The connection can support multiple devices. It can be enabled or disabled on the router with buttons and the LCD display or on the Web page

2.3 Power

The material feed may be made in DC voltage or AC voltage.




Figure 7
The rear power connector

The power connector is a clips connector. Wire is inserted using a screwdriver 2.5mm or a suitable tool.




Figure 8
Insert wire in power connector

2.4 Wiring

According to the reference with 1, 2, 3 or 4 EIA-709 ports, ports are used, starting with the left.

According to reference product 1, 2, 3 or 4 EIA-485 ports, the ports are used starting from left or following EIA-709.

| Reference | Port 1 | Port 2 | Port 3 | Port 4 |
|------------|-----------|-----------|---------|--------|
| Ox-1Lo-1Mo | TP/FT10 | EIA-485 | | |
| | EIA-709.1 | Modbus | | |
| Ox-1Lo-2Mo | TP/FT10 | EIA-485 | EIA-485 | |
| | EIA-709.1 | Modbus | Modbus | |
| Ox-2Lo-1Mo | TP/FT10 | TP/FT10 | EIA-485 | |
| | EIA-709.1 | EIA-709.1 | Modbus | |

2.5 Wired network EIA-709.1 / EIA-485 Modbus

The EIA-709 protocol is not polarized; the front connectors are identified in groups by three, left to right: Earth Net A and B.

Modbus over EIA-485 is polarized. Be careful, you must connect the + of all equipment on the right terminal and the - pole on the left terminal.



When the devices are powered by different sources, the third connector must be connected to the reference.



Figure 9
Wired connection TP/FT10
CEA_709.1




Figure 10
Stick network connector TP/FT10 and EIA-485



A polarity inversion does not damage device, but the communication does not works.

2.6 LED signalization

2.6.1 Power LED

The **POWER** LED is ON in Green at the beginning of power on. A red color indicates a fault on the router.

2.6.2 Wifi LED

For Oxtopus routers with wifi option, **WIFI** LED will be green to indicate that wifi is active; the red color indicates that the wifi is inactive.

For routers that do not have wifi, this LED is off.

2.6.3 IP1/IP2 LED

IP LEDs indicates the status of each port and architecture

| LED | Ethernet architecture |
|------------|--|
| LED IP1 ON | IP Ports works in « switch » mode |
| LED IP2 ON | Ports are configured in « double IP » |

Regardless of the architecture, the color of the LED indicates the operation of the connection.

A green LED indicates that the Ethernet connection is working properly.

A red LED indicates that the Ethernet connection is not working. This may be due to the inability to retrieve an IP address via DHCP for example.

Finally, an orange LED indicates that the Ethernet connection is working, but a fault has been detected during startup. Services such as CNIP (LON 852) Config Server and Modbus do not work. This may be due to, for example, significant time between the router startup and recovery of an IP address via DHCP. In this case the DHCP worked but the address was acquired too late, the services were launched without IP.

2.6.4 LED Activity (« Act. »)

2.6.4.1 LON FT/TP-10

EIA 709 Port of Oxtopus router has a bicolor LED:

| Behavior | Description | Comment |
|-----------------------|---------------------|---|
| GREEN blinking | Traffic | Receiving or sending frame |
| GREEN blinking at 1HZ | Port Not configured | |
| RED blinking | Errors on medium | Lost frame due to: <ul style="list-style-type: none">- CRC Error- Most important Traffic |

2.6.4.2 Modbus RS485

A Modbus-RS485 port of Oxtopus router has a bicolor LED:

| Behavior | Description | Comment |
|----------------|------------------|-----------------------------------|
| GREEN blinking | Traffic | Receiving or sending frame |
| RED blinking | Errors on medium | Lost frame due to: - CRC Error |

2.6.5 LED Z

It is used to view the state of the line impedance: fault if line break or termination not connected at each ends.

LED in GREEN indicates that impedance is good.

LED in RED indicates that impedance is fault.

2.7 Screen

The Oxtopus Router has a LCD screen in front. When the router starts, the screen displays the logo "Occitaline" and the name of the router.



Figure 11 : Home screen

The buttons below the display are used to navigate in the menu.

Press one of the buttons to access the menu which indicates the router configuration and bandwidth usage in real time to the ports LON FT / TP10.



Figure 12 : First page menu

Buttons below the arrows are used to select the port. Once selected, press the button under the symbol "**SP**" (Service Pin) to send a service pin of the Neuron Chip of that port.

Whatever the selected port, the button under the symbol "**GSP**" allows you to send a service pin of each external Neuron Chip on router.

Finally, the page after Ports show you the IP address of the router.



Figure 13 : IP page

3 Easy and fast setting

3.1 Wizard for configuration

A wizard has been developed to simplify the configuration of Oxtopus router.

Questions are asked in specific order. At the end of the sequence, the reboot of the router places it in the desired configuration.

The steps are:

1. System
2. Configure Wifi
3. EIA-709 Configuration
4. Modbus configuration
5. Reboot

When the reference does not have Wifi, EIA-709 or Modbus, the corresponding step is simply skipped (not showed) from the wizard.

All changes in the configuration Wizard will be saved at the last step. You can redo the Wizard as many times as you like without saving. All temporary values are stored until the backup or closing your session with the browser.

3.2 Starting wizard on home page

The actions menu is on the left. The user identification is at the top right of the page.

The home page shows the status of the router. (For more details see chapter 0)




Figure 14
Home page and Easy installation menu


3.3 Login page

When access to a configuration page, if the user is not logged, the login page is proposed. (See Chapter 3.3)

The account is "**admin**", password is "**oxpass**".

3.4 Name of router

The name will be visible on the LCD screen and in the members list of the Channel IP.




The screenshot shows the Occitaline web interface. On the left is a sidebar with menu items: Device-info, Configuration, Stats, Log, and Easy Installation (highlighted). The main area is titled 'Configuration system'. Below the title is a 'Name' label and a text input field containing 'Oxtopus_01'. There are 'Back' and 'Next' buttons at the bottom of the form.

Figure 15
Define router name


3.5 IP address

The router can obtain an IP address by DHCP server or you can define a fixed IP address.



The screenshot shows the Occitaline web interface for 'Configuration ETH0'. The 'Enable DHCP' radio button is selected, and 'Disable DHCP' is unselected. There are 'Back' and 'Next' buttons at the bottom of the form.

Figure 16
Router with dynamic IP address




The screenshot shows the Occitaline web interface for 'Configuration ETH0'. The 'Disable DHCP' radio button is selected, and 'Enable DHCP' is unselected. Below this, there are fields for 'IP address' (192.168.3.31), 'Netmask' (255.255.255.0), 'Gateway', 'DNS 1', and 'DNS 2'. There are 'Back' and 'Next' buttons at the bottom of the form.

Figure 17
Router with fixed IP address


3.6 Wifi configuration

This page allows you to enable or disable the Wifi as well and set the access parameters.



*Figure 18
Disabling Wifi option*

If WiFi is activated from the LCD screen, the values stored in the configuration will be used. By enabling WiFi by the Web, you can change its setting.




*Figure 19
Wifi setting*

| | |
|--------------|---|
| SSID | It defines the visible name usable by your PC, tablet or smart phone. |
| Pass Phrase | This is the passcode to enter to validate the connection. |
| WPA | This is the security mode Wifi access. |
| WPA Pairwise | This is the encryption connection. |
| Channel | This is the channel frequency for wireless connection. |

3.7 EIA-852 configuration


The router side IP must be a member of an IP Channel. The router can handle this task with its "Server Config".

Default routers come with the "config server" disabled.




*Figure 20
EIA-852 setting without Config Server*

In case of the "config server" is on another device, you must define the IP address of it and the port (default 1629).



*Figure 21
EIA-852 setting with Config Server and adding router to the Channel IP*

In case of "Config Server" enabled, the router can automatically be added to its list of members and you can no longer enter the address of the "Config Server".



Occitaline

Device-info
Configuration
Stats
Log
Easy installation

Parameter for LonWorks router

Config server rule

Do you want to activate the config server? ☒ Yes ☐ No

Address and port config server

192.168.3.31 1629

Add the router to the channel list? ☐ Yes ☒ No

EIA-852 Client rule

EIA-852 Client IP and Port

192.168.3.31 1628


My config server address

192.168.3.31 1629

Back Next

Figure 22
EIA-852 setting with Config Server WITHOUT adding router to the Channel IP

If you do not want to add the router to the members of Channel IP managed by this router, you must enter the address of its "Server Config".



Occitaline

Device-info
Configuration
Stats
Log
Easy installation

Channel list

Add a new member

Channel name

Oxtopus_CS

Show 10 entries

| Name | IP address | Port | Status | Enable | Edit | Edit |
|------------|--------------|------|--------|-------------------------------------|------|--------|
| Oxtopus_01 | 192.168.3.31 | 1628 | --- | <input checked="" type="checkbox"/> | | |
| Oxtopus02 | 192.168.3.26 | 1628 | --- | <input checked="" type="checkbox"/> | Edit | Delete |

Showing 1 to 2 of 2 entries

Previous 1 Next

Back Next

Figure 23
Member list of the Channel IP

On the first time on this page, if you have checked the checkbox "Adding the router to the members", only the router is added. In this case, the first line shows the router's name and IP address. The edit and delete buttons are not available.

3.8 Modbus configuration

This page defines the communication port used by the Modbus IP Server (default 502). The protocol is TCP / IP.

A field also sets a rerouted slave address to get Modbus ports and EIA-709.1 statistics of routers's Neuron Chip.




Figure 24
Server Modbus IP setting

If the router is equipped with EIA-485 port for Modbus, for each port you can configure speed, parity, stop bits and size.




Figure 25
Serial ports EIA-485 setting

The source address is the address requested by Modbus Client on IP. The port is the line that will be sent. The request destination address is the real slave address of the device connected on line.




Figure 26
Translation address table for Modbus

3.9 Confirm and reboot

This page will record into the router all parameters entered by the user.




Figure 27
Validation du Wizard

The values will be used after the reboot or by turning off / on the router.




Figure 28
Router reboot

After validation, wait for 15 to 20 seconds for restart.




If you changed the IP address, the browser cannot find the router. You may need to change the address of your PC to be in the same subnet and enter the new router IP address to find its home page.

4 Details settings


4.1 Resizable page to the screen device

The Web site is automatically adapted to the device that consults.



*Figure 29
Home page on computer*

When the device menu width no longer fits to the left, it is reduced and can be opened by the top right button.



*Figure 30
Home page on tablet in portrait*

4.2 Home page

The home page displays the router's condition: configuration, impedance mismatches, sending services pin of each EIA-709.1 ports.

This page is not protected by password.





Figure 31
Complete home page

Several panels are displayed according to the reference product.

4.2.1 Device info

Device-info



| Oxtopus [Ox-3Lo-1Mo] | |
|-----------------------|--------------------------|
| Nom | Oxtopus_01 |
| Date | 2015-06-05 |
| Heure | 11:41:00 |
| Architecture ethernet | Switch |
| Wifi | <input type="checkbox"/> |

Figure 32
General Information

Reference of the product is shown in banner title.

| | |
|--------------|--|
| Nom | This is the name of the router that is found among others on the LCD. |
| Date/Time | This is the current time of the router. It is used for log errors and statistics. |
| Architecture | It is the use of the two RJ45 connectors for Eth0 Eth1. The current mode is "Ethernet switch." |
| Wifi | indicates if WiFi is active or No. |
| SSID | When WiFi is active, this is the name of the visible WiFi access in devices used for connection. |





Figure 33
Oxtopus router

Under the image, the button "GENERAL SERVICE PIN" sends the service pin of all ports simultaneously. Red or green circles at the bottom right indicates the ports fault impedance on each line.

4.2.2 Ethernet chapter

Chapter Eth0 indicates all services provided by the router via Ethernet

ETH0




| Général | | Port LON [Config server] | | Port Lon [Client/Routeur] | | Port Modbus Server | |
|---------|-----------|--------------------------|------------|---|-------------|--------------------|---------|
| IP | 127.0.0.1 | Channel name | Oxtopus_CS | NID externe | 38000000100 | Port | 502 |
| | | Nb de membre | 2 | NID interne | 38000000101 | Protocoles | TCP |
| | | | | Mode | Configured | Statistique LON | Archive |
| | | | |  SERVICE PIN | | Statistique Modbus | Archive |

Figure 34
General services on IP

4.2.2.1 General panel

IP IP address of router.

4.2.2.2 Config Server panel

Channel name This is the name of channel IP for rule « Config Server ». This name is only used by the user. He has no rule in the protocol.

Nb member Number of members declared in channel list.

4.2.2.3 Router EIA-852 Client panel

NID extern Neuron Id on router EIA-709 IP side.

NID intern Neuron Id on IP router internal side.

Mode Routing mode EIA-709. (Configured, Repeater, Learning,...)

4.2.2.4 Modbus server IP panel

Port Communication port for Modbus IP server.

Protocol TCP: IP Protocol used for Modbus IP server.

Stat Lon Indicates logs router EIA-709 statistics to view them graphically.

Stat Modbus Indicates Modbus Router logs Modbus statistics to view them.

4.2.2.5 BACnet IP panel

BACnet routers have an additional inset screen :

| Port BACnet [BACnet IP/Device Object] | |
|---------------------------------------|-------------------|
| Port | 47808 |
| device ID | 200 |
| device name | OX-BAC-RT-IP/MSTP |
| BACnet/IP network | 1 |

Figure 35 BACnet IP general information

| | |
|-------------------|---|
| Port | BACnet IP communication port |
| Device ID | « Device Object » BACnet. identifier |
| Device name | Name of the BACnet object as entered by the user. |
| BACnet/IP network | BACnet IP « Network » number. All routers on the same BACnet / IP network must have the same network. |

4.2.3 Ports chapter

In accordance with the reference product, the ports used are from 1 to 4. Each of them can be supplied for use in EIA-709 or Modbus.

Ports










| Port1 [LON] | Port2 [LON] | | | | | | | | | | | | | | | | | | |
|--|--------------------------|--------------------------|-------------|--------------------------|--------------|------------|---|--|--|-------------|--------------------------|-------------|--------------------------|--------------|------------|---|---|------|-----|
| <table border="1"><tr><td>NID externe</td><td>38000000102 - Configured</td></tr><tr><td>NID interne</td><td>38000000103 - Configured</td></tr><tr><td>Type routeur</td><td>Configured</td></tr><tr><td colspan="2"></td></tr></table> | NID externe | 38000000102 - Configured | NID interne | 38000000103 - Configured | Type routeur | Configured |  | | <table border="1"><tr><td>NID externe</td><td>38000000104 - Configured</td></tr><tr><td>NID interne</td><td>38000000105 - Configured</td></tr><tr><td>Type routeur</td><td>Configured</td></tr><tr><td colspan="2"></td></tr></table> | NID externe | 38000000104 - Configured | NID interne | 38000000105 - Configured | Type routeur | Configured |  | | | |
| NID externe | 38000000102 - Configured | | | | | | | | | | | | | | | | | | |
| NID interne | 38000000103 - Configured | | | | | | | | | | | | | | | | | | |
| Type routeur | Configured | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | |
| NID externe | 38000000104 - Configured | | | | | | | | | | | | | | | | | | |
| NID interne | 38000000105 - Configured | | | | | | | | | | | | | | | | | | |
| Type routeur | Configured | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | |
| Port3 [LON] | Port4 [MODBUS] | | | | | | | | | | | | | | | | | | |
| <table border="1"><tr><td>NID externe</td><td>38000000106 - Configured</td></tr><tr><td>NID interne</td><td>38000000107 - Configured</td></tr><tr><td>Type routeur</td><td>Configured</td></tr><tr><td colspan="2"></td></tr></table> | NID externe | 38000000106 - Configured | NID interne | 38000000107 - Configured | Type routeur | Configured |  | | <table border="1"><tr><td>Baudrate</td><td>115200</td></tr><tr><td>Parity</td><td>None</td></tr><tr><td>Stop</td><td>1</td></tr><tr><td>Size</td><td>8</td></tr><tr><td>Mode</td><td>RTU</td></tr></table> | Baudrate | 115200 | Parity | None | Stop | 1 | Size | 8 | Mode | RTU |
| NID externe | 38000000106 - Configured | | | | | | | | | | | | | | | | | | |
| NID interne | 38000000107 - Configured | | | | | | | | | | | | | | | | | | |
| Type routeur | Configured | | | | | | | | | | | | | | | | | | |
|  | | | | | | | | | | | | | | | | | | | |
| Baudrate | 115200 | | | | | | | | | | | | | | | | | | |
| Parity | None | | | | | | | | | | | | | | | | | | |
| Stop | 1 | | | | | | | | | | | | | | | | | | |
| Size | 8 | | | | | | | | | | | | | | | | | | |
| Mode | RTU | | | | | | | | | | | | | | | | | | |

Figure 36
General on ports

4.2.3.1 EIA-709 port

| | |
|--------------|---|
| NID external | External Neuron Id of router. |
| NID internal | Internal Neuron Id of router. |
| Type router | Routing mode chosen by your manager tool. |

4.2.3.2 Modbus port

| | |
|----------|--|
| Baudrate | Speed of serial port. |
| Parity | Parity of serial port. |
| Stop | Number of stop bit for serial port. |
| Size | Size of each word for serial port (Modbus 8 bits). |
| Mode | Mode usage of serial port in Modbus « RTU » |

4.2.3.3 BACnet MSTP port

| Port3 [BACnet MSTP] -Port activé- | |
|-----------------------------------|-------|
| Adresse MAC MSTP | 0 |
| Numéro de Network | 2 |
| Baudrate | 38400 |

Figure 37 BACnet MSTP general information

| | |
|------------------|--|
| MAC MSTP Address | BACnet MS/TP port MAC Address |
| Network | Network number MS / TP. Must be unique for each MS / TP port. |
| Parity | Configuring the parity of the words of the serial communication. |

4.3 Menus

Menus are displayed on the left with a sufficient width terminal. If the width does not allow it, they fold out with the top right button. We find:

| | |
|-------------------|---|
| Device info | Home page |
| Configuration | Organized in system, Ethernet, Wifi, EIA-709.1 and Modbus |
| Stats | Graphical statistics |
| Log | Logs of communication and error |
| Easy Installation | The wizard |




Figure 38
Menus example

4.4 Login page

When access to a configuration menu, if the user is not logged in, a login page is proposed. It is also possible to call this page from the top right menu: "Connection." The account is "**admin**" password is "**oxpass**".




Figure 39 identification page

4.5 User modification account




Figure 40
User modification page


With this page, the user can change his password and his language used after connection.



The language for « guest user» modifies the default language for not logged users.


4.6 Reboot page

This page will log into the router all the parameters entered by the user.



*Figure 41
Wizard confirmation*

The values will take effect after the reboot page or by turning off / on the router. After validating this page, you need to wait 15 to 20 seconds to reboot.




*Figure 42
Router reboot*



If you changed the IP address, the browser cannot find the router. You may need to change the address of your computer in same subnet and enter the new router IP address to find its home page.

4.7 System configuration

This page allows you to change the router's name, date and time.




The screenshot shows the Occitaline web interface. On the left is a dark sidebar menu with the following items: Device-info, Configuration (expanded), Configuration system (highlighted), Configuration ETH0, Configuration LON, Channel list, Configuration Modbus, Stats, Log, and Easy installation. The main content area is titled 'Configuration system'. It contains a 'Name' field with the value 'Oxtopus_01' and 'Save' and 'Cancel' buttons. Below this is a 'Date/Time' section with an 'Enable NTP' button, a 'Date' field with '08/06/2015', a 'Time' field with '17:18', and 'Save' and 'Cancel' buttons.

Figure 43
Configuration system

4.8 Configuration

This page allows to select the router's addressing mode. Either the IP address is dynamically assigned on the network by a DHCP server or it is manually assigned and called "static IP" address.



The screenshot shows the Occitaline web interface. The sidebar menu is the same as in Figure 43, but 'Configuration ETH0' is now highlighted. The main content area is titled 'Configuration ETH0' and contains a 'Disable DHCP' button.

Figure 44
ETH0 configuration with DHCP



All modification of IP address takes effect after reboot.




Figure 45
Configuration ETH0 with fixed IP

4.9 Port EIA-709

This page serves only to display the configuration of the EIA-709 router ports.




Figure 46
Configuration des ports EIA-709

4.10 Port EIA-852 Client

This page allows you to change the communication port for data exchange in EIA-852 Client (1628 by default) and the IP address and port (1629 by default) for the config server.




Figure 47
EIA-852 client configuration

Its config server is not necessarily the router itself. That may be another router or a computer. It will specify the IP address and port used for this function.



An EIA-852 port that has no config server cannot know the member with which he must share data. The network will not work.



There can be only one "config server" EIA-852 client

4.11 The config server

The router is delivered with the Config Server disabled. To enable and configure it, just click the button. **"Enable the config server."**




Figure 48
Config server disable

The IP address of the config server is IP address of the router itself. The port can be changed. The default value is 1629.




Figure 49
Config server activated

4.12 Channel list

This page allows adding, removing, enabling, exporting, importing and test members of IP channel. All members of the list are likely to share data. They will be installed in one or more LNS databases.




Figure 50
Liste des membres du Channel

The role of the Config Server is like a "virtual electrician" that will connect all devices on the same wired network.

4.13 Modbus server Stat EIA-709 configuration

This page provides the Modbus slave address to query the router on the statistics of external Neuron Chip of routers, status and Modbus Serial ports as impedance.




Figure 51
Configuration of slave address for statistics.

Each Neuron Chip has a base address and each counter is set to a 16-bit word.



The reading is done by a read command on an "Input Register" Modbus.

4.14 Modbus serial Ports configuration

This page allows to change all the serial parameters for Modbus serial ports




Figure 52
ModBus serial port configuration

4.15 Modbus NAT router configuration

This page allows to add, delete, edit, export and import translations Modbus Source slave address to a destination slave address on a serial port to join device.




Figure 53
Router NAT Modbus configuration

To each source slave address matches a serial port and a destination slave address on that port. This table allows to use the same destination slave addresses on all serial ports.

4.16 BACnet Configuration

4.16.1 Device and BACnet IP



Figure 54 Configuring the BACnet IP and BACnet Device Object

This page allows you to configure the parameters described below:

| Parameter | Default value | Description |
|--------------------|----------------------------------|---|
| BACnet/IP UDP port | 47808 (BAC0) | BACnet UDP Port. All BACnet modules on the same network must have the same port. |
| BACnet/IP network | 1 | Can take a value from 1 to 65534. Represents the "network" number associated with the IP channel. All routers in the same network must have the same Network IP number. |
| Name | Ox-BAC-RT-IP/MSTP | Router name. This name will be visible through the BACnet network. |
| Device ID | 152000 | Unique identification number of the module on the BACnet network. WARNING, all routers come with a default ID of 152000. It's up to you to modify them. Each device on the network must have a unique ID. |
| Description | BACnet Router BACNet/IP and MSTP | Description associated with the BACnet router. This description will be visible through the BACnet network. |

4.16.2 MSTP Ports




Figure 55 Configuring the MSTP bus line on RS-485

| Parameter | Default value | Description |
|----------------|---|---|
| Baudrate | 38400 | MS / TP communication speed. All modules on the same MS / TP bus must have the same communication speed. |
| Network number | « 100x », avec x numéro du port BACnet. | Can take a value from 1 to 65534. Represents the "network" number associated with the MS / TP channel. The Network number must be unique for each MS / TP bus. |
| MAC MS/TP | 0 | Allowable values range from 0 to 127. MAC address of the MS / TP port of the router. Must be unique on the bus. |
| Max master | 127 | Allowable values range from 0 to 127. Must be equal to the largest MAC address number accessible on the MS / TP port. Setting this parameter will improve the performance of your network. |
| Max frame | 10 | Allowable values range from 0 to 100. Specifies the maximum number of frames that the router can send on the MS / TP before passing the Token. Too high value can reduce the performance of your network. |

5LON Scheduler

5.1 Overview

Since the LON Scheduler is made up of several blocks, one BACnet the other in LON, it is necessary to set each of these blocks. In addition, the LON node must be added to the Config Server in order to connect to the "Channel IP". The LON Node will also need to be installed in the database via NL220 or equivalent. The steps for configuring and installing the LON node are described in this chapter.



The "Scheduler LON" node is embedded in the Oxtopus but is unlinked from the LON router. These are two separate applications, equivalent to two nodes present on the Oxtopus. The router AND the LON scheduler must therefore be installed via NL220 or equivalent.

5.2 The home page

When the Scheduler option is active in the Oxtopus router, an additional line appears on the cover page indicating elements related to the BACnet and LonWorks part.

ETH0

| General | Port LON [Config server] | Port LON [Client/Router] | Port Modbus Server |
|------------------------------|---------------------------|-----------------------------|---------------------------|
| IP address192.168.0.253 | Channel IP nameOxtopus_CS | External NID038000002254 | Port502 |
| Netmask255.255.255.0 | Nb of member declared2 | Internal NID038000002255 | ProtocolTCP |
| MAC address48:EE:0C:F2:C4:FF | Nb of member enabled2 | Router statusUnconfigured | Slave Address stat Lon240 |
| | | Service Pin | Nb Modbus NAT3 |

ETH0 ... Schedules

| BACnet device | Port EIA 852 for Scheduler |
|---|------------------------------|
| BACnet port47808 | Neuron IDFE771A7697EB |
| Device ID10123 | Node statusapp, unconfigured |
| Device NameDevice Router - Scheduler Occitaline | Node Port1631 |
| Device DescriptionBACnet Scheduler link to Lon node | Number of variables50 |
| Network number1 | Service Pin |

Figure 56 Scheduler home page

The Pin service button is available on the cover page, as for the router.

5.3 Configuration

5.3.1 Scheduler menu

When the Scheduler option is active in the Oxtopus router, three menu appears onto the left side





Figure 57 Scheduler menu

| | |
|------------------------|--|
| BACnet Device | BACnet scheduler configuration. |
| LonWorks Device | LonWorks scheduler configuration. |
| Scheduler | Assign the values of the network variables according to the enumeration value. |

5.3.2 LonWorks configuration

5.3.2.1 LonWorks device menu

The LonWorks configuration page allows you to view the state of the node, its physical and logical addresses.



Occitaline

Device-info: Ox-1Lo-1Mo-Sc-Wi

Configuration

- Configuration system
- Configuration ETH0
- Configuration WIFI
- Configuration LON
- Configuration Modbus
- Config Scheduler**
- BACnet device
- LonWorks device**
- Scheduler

Configuration LonWorks for Scheduler

| | |
|--------------------|----------------------------|
| Neuron ID | Domain size / value |
| FE771A7697EB | 1 / 00 |
| Subnet/Node | Node status |
| 0 / 0 | app, unconfigured |

Port EIA-852 Client

1631

Ce port doit être différent de celui du routeur s'il est configuré sur le même Channel IP (config server)

Save **Cancel**


Figure 58 LonWorks configuration page

It is possible to modify the communication port of the LonWorks Scheduler node. This must be different from the communication port of the router. If the router and the node scheduler are in the same "Config Server", it is imperative to inform the two elements with the same IP address and their respective ports.

5.3.3 BACnet configuration

5.3.3.1 Device BACnet menu

Any BACnet device must have a "Device" object. The identifier of this device, or "device ID" must be unique in the BACnet project. Device ID settings are done by the website page.



Occitaline

Device-info: Ox-1Lo-1Mo-Sc-Wi

Configuration

- Configuration system
- Configuration ETH0
- Configuration WIFI
- Configuration LON
- Configuration Modbus
- Config Scheduler
- BACnet device**
- LonWorks device
- Scheduler

Configuration BACnet for Scheduler

Device Name

Device Router - Scheduler Occitaline

Device Description

BACnet Scheduler link to Lon node

Device ID

10123

BACnet port

47808


Save Cancel

Figure 59 BACnet properties configuration page

You can change the description of the Device BACnet object, its logical address in the project and the communication port. The default port in BACnet is 47808.

5.3.3.2 Network variable values, label and Enumeration

Each scheduler is associated with an object of type "multi-state-output". This object allows the association to a label a value to create an enumeration. Each multi-state-output can contain 5 enumerations by default.



Occitaline

Welcome : admin EN

Configuration Enumeration values BACnet -> LonWorks

Select the scheduler you want to modify

Scheduler 1 & Scheduler 2

| Enum | Enum name | temp_p | occupancy | switch.state | switch.value | lev_percent | setting-function | setting | rotation |
|------|-------------|--------|-----------|--------------|--------------|-------------|------------------|----------|----------|
| 1 | Occupé | => | 23 | OC_OCCUPI | -1 | 0 | 163.835 | SET_NULL | 0 |
| 2 | Standby | => | 18 | OC_STANDB | -1 | 0 | 163.835 | SET_NULL | 0 |
| 3 | Inoccupé | => | 16 | OC_UNOCCU | -1 | 0 | 163.835 | SET_NULL | 0 |
| 4 | En vacances | => | 327.67 | OC_NULL | -1 | 0 | 163.835 | SET_NULL | 0 |
| 5 | Val 5 | => | 327.67 | OC_NULL | -1 | 0 | 163.835 | SET_NULL | 0 |

Save Cancel

Figure 60

Configuring values for network variables based on enumeration


The enumeration thus created Val1, Val2, Val3 ... are the values that can take the "present value" of the Scheduler.

5.3.3.3 Configuration of the time program and the exceptions

Once correctly set, via a BACnet explorer you can view and configure your time programs.

All time program configurations can be done directly via BACnet.


An example is shown below for which we use the Inneasoft BACnetExplorer (<http://www.inneasoft.com/index.php/fr/produits/bacnet-protocole/bacnet-explorateur>).



| | | |
|-----|---------------------------------|--|
| 155 | Database Revision | 1 |
| 24 | Daylight Savings Status | True |
| 28 | Description | BACnet Scheduler link to Lon node |
| 44 | Firmware Revision | 0.9.1 |
| 56 | Local Date | mardi 16 mai 2017 |
| 57 | Local Time | 13:18:52 |
| 58 | Location | Europe/France |
| 62 | Max Apdu Length Accepted | 1476 |
| 70 | Model Name | Ox-BAC |
| 75 | Object Identifier | DEVICE:152000 |
| 76 | Object List | {DEVICE:152000 ; SCHEDULE:0 ; SCHEDULE:1 ; SCHEDULE:2 ; SCHEDULE:3 ; |
| 77 | Object Name | Device Router - Scheduler Occitaline |
| 79 | Object Type | Device (8) |
| 96 | Protocol Object Types Supported | {0 ; 0 ; 0 ; 0 ; 0 ; 0 ; 0 ; 0 ; 1 ; 0 ; 0 ; 0 ; 0 ; 1 ; 0 ; 0 ; 0 ; 0 ; 0 ; 0 ; |
| 139 | Protocol Revision | 14 |

Figure 61
Occitaline Scheduler overview from the explorer

Create your schedule according to the enumerations previously configured in section 5.3.3.2



| Programme Horaire | | Propriétés | |
|-------------------|--|------------|----------------|
| État : | | Force_Cold | Nouvel état... |
| | | Force_Cold | |
| | | Force_Heat | |
| | | Inoccupied | Mercredi Jeudi |
| | | Occupied | |
| | | Standby | |
| 0 | | | |
| 1 | | | |
| 2 | | | |
| 3 | | | |
| 4 | | | |
| 5 | | | |
| 6 | | | |
| 7 | | | |
| 8 | | | |
| 9 | | | |
| 10 | | | |

Figure 62
Enumerations previously configured



Figure 63
Time program example

In the same way, exceptions can be created / edited / deleted directly through the BACnet.



You can force values by putting the scheduler in "out_of_service". In "out_of_service", any writing on the present value of the scheduler is immediately reflected on the LonWorks outputs.

5.3.4 LON node installation

The LON node "Scheduler" is a LON / IP node. It is therefore mandatory to register it on the config server of the IP channel. The server configuration can be the router itself or any other device that supports the server configuration function. By default, the LON Scheduler node is on port 1630. It is with this port number that you must register the node on the server configuration.

5.3.5 Installing template files

The files "OX-SCHED01.XFB", "OX-SCHED01.xfo", "OX-SCHED01.xif" downloadable from our website and "spidData.xml" are downloadable from our lonmark.org.

The file "spidData.xml" must to be copied, according to OS, into the directory:

- **C:\Program Files (x86)\LonWorks\Types** for 64bits or
C:\LonWorks\Types for 32 bits
- And in the case of the use of NL220, **C:\Program Files (x86)\Newron System\NL220\Bin**

The files "OX-SCHED01.XFB", "OX-SCHED01.xfo", "OX-SCHED01.xif" are to be copied, according to OS, into the directory:

- C:\Program Files (x86)\LonWorks\import\Occitaline or
- C:\LonWorks\Import\Occitaline



If the Occitaline directory folder does not exist, create it.

5.3.6 Adding the LON scheduler to an Oxtopus config server

The LON scheduler node is added like any other node. Be careful though, port 1628 (LON default port) is already used for the router. **The LON Scheduler is declared on port 1630.**

Log on to the website. Via the menu, select "Configuration", "LON Configuration", "Channel list".


On the page that appears, click on the button  which opens you a pop-up. Fill in the fields and validate.



Figure 64
Added a LON Scheduler to the channel list.

The server configuration then contacts the node and exchanges the channel information with it. When the exchanges are completed, the node must appear "Registered" in the list.




| | | | | | | |
|--------------|--------------|------|--|-------------------------------------|--|---|
| Oxto_65_NODE | 192.168.3.65 | 1630 |  Registered | <input checked="" type="checkbox"/> |  Editer |  Supprimer |
|--------------|--------------|------|--|-------------------------------------|--|---|

Figure 65
The LON Scheduler node correctly added to the channel list.

5.3.7 Installation in an LNS base with NL220

Create a node (here from the template) and name it.




Figure 66
Create a node (here from the template) and name it.

Install the node. Select the node, right click, "Network" then click on "Install ..."





Figure 67 Node installation

The window that opens is waiting for a Neuron ID to continue. The Neuron ID is received directly from the network. To do this, connect to the Oxtopus website where the Scheduler is to be installed. On the LonWorks Node block, click on the  button.

You must have received the PIN service on NL220, which has automatically filled the following window.




Figure 68
Node installation window

Click on "Continue".

Wait until the node is properly installed.

5.3.8 Binding

Scheduler takes advantage of LON bindings. "Bind" Scheduler nvo on the nvi of the modules you want to control. At each time zone change, the values are updated and automatically sent to their recipient (s).

The image below shows the installed node, its 5 functional blocks (ROOM_X), each with 5nvi / 5nvo.




Figure 69
LON Scheduler Installed and Function Blocks

In the case of the image above, the nvoSpaceTemp01 is bound. As a reminder, the functional block is linked to scheduler 1 and 2 (for alternating summer / winter, see 1.5.4). On change of

time slot, the new value of nvoSpaceTemps01 will be automatically propagated to the nodes to which it is bound.


6 Configuration via USB

6.1 General Information

For the USB driver installation and terminal, refer to the annexes 8.2 and 8.3.

When your device is running and configured, press the "Enter" key to display the menu. There are two choices:


- Restore the default IP address **192.168.1.254**
- To restart



*Figure 70
Screen on terminal connected to the router*

6.2 Default IP address

To force the default IP address, select "1" on your keyboard, and confirm by pressing "enter"



*Figure 71
Confirmation load manufacturer values by "Y"*

The interface asks you to confirm by pressing "Y" or "N" to return to main menu



The changing IP address will be effective after restart. Please note that restart is not done automatically after the IP address change

6.3 Restarting

To reboot, select the "2" key on your keyboard, and confirm by pressing "enter".




Figure 72
Confirm Reboot by "Y"

The interface asks you to confirm by pressing "Y" or "N" to return to main menu

7 Smart Channel usage

7.1 Preamble



To simply use the Oxtopus routers in NL220 or NLFacilities you must have placed specific files in the directory NLSmartChannel. See Appendix 8.1

These routers are equipped with an Ethernet port with an Ethernet switch on two RJ45 connectors and 1, 2, 3 or 4 ports TP / FT10. Some models can be equipped with 1, 2 or 3 Modbus ports. These are considered invisible in NL220.

Model to be installed in Smart Channel

| Référence | Modèle à installer dans Smart Channel | | | |
|---------------|---------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|
| | Ox-1Lo | Ox-2Lo | Ox-3Lo | Ox-4Lo |
| Ox-1Lo | <input checked="" type="checkbox"/> | | | |
| Ox-1Lo-Wi | <input checked="" type="checkbox"/> | | | |
| Ox-1Lo-1Mo | <input checked="" type="checkbox"/> | | | |
| Ox-1Lo-1Mo-Wi | <input checked="" type="checkbox"/> | | | |
| Ox-2Lo | | <input checked="" type="checkbox"/> | | |
| Ox-2Lo-Wi | | <input checked="" type="checkbox"/> | | |
| Ox-2Lo-1Mo | | <input checked="" type="checkbox"/> | | |
| Ox-2Lo-1Mo-Wi | | <input checked="" type="checkbox"/> | | |
| Ox-3Lo | | | <input checked="" type="checkbox"/> | |
| Ox-3Lo-Wi | | | <input checked="" type="checkbox"/> | |
| Ox-3Lo-1Mo | | | <input checked="" type="checkbox"/> | |
| Ox-3Lo-1Mo-Wi | | | <input checked="" type="checkbox"/> | |
| Ox-4Lo | | | | <input checked="" type="checkbox"/> |
| Ox-4Lo-Wi | | | | <input checked="" type="checkbox"/> |

7.2 Main channel modification

If the channel type on which you want to install the router is not IP10L, you can modify it by editing it.




Figure 73
Editing Channel type

The name and type can be changed to fit to your project.




Figure 74
Name and type of channel

Once entered, you need to update by clicking the "Update" button.




Figure 75
Channel modified following your needs

NLSmartChannel assists you in adding your project infrastructure products. Media types are checked. By adding an Oxtopus router, the IP port will always be connected to a channel IP-10L




Figure 76
Adding an infrastructure device




Figure 77
Oxtopus routers

You only have to choose the router version you want to install.

After validation, you can resume operations to add another router of the same type or a different one.




Figure 78
Plusieurs routeurs de type différents peuvent être ajoutés.

With "CTRL-" shortcut or the installation menu, you can access the installation window below.




Figure 79
Entering the NEURON Id

If the router is turned on and connected to the Ethernet network, you can get its IP address by navigation with the buttons under LCD screen of router.




Figure 80
IP address of Oxtopus router.

This address is used in your Web browser to view the embedded Web server in the router Oxtopus.




Figure 81
Home page of Oxtopus router

On the home page you have a "General Service Pin" button.

Each port sends its Neuron Id outside of the router. You will therefore be able to install the IP router in first. Then, for the other ports, you can activate the buttons on the home page or choose the port on the LCD screen and press the "[SP]."

When you have entered all the Neuron Id and closed the window, you will find that the router is green in the tree. It is now operational.




Figure 82
Router installed in LNS database

8 Appendix

8.1 Resources installation for NLSmartChannel

The compressed file "NL220_Resources.rar" allows software tools NL220 and NLFacilities to easily install the range of Oxtopus routers.




Figure 83
Contain compressed file for NLSmartChannel

Each directory in the compressed file contains files for defining Oxtopus routers.




Figure 84
Directory where the files must be installed

When the files are installed you will find the following directories:




Figure 85
Directory XML



Figure 86
Directory Image




Figure 87
Directory Document


8.2 USB driver installation

8.2.1 On Windows 8


Under Windows 8 when you plug the USB cable, the device is recognized automatically.

8.2.2 On Windows XP / 7


Under Windows XP, it is necessary to install the USB driver manually. To do this, connect the USB cable to the router and on the computer. When the "Wizard Add Hardware" appears, select "No, not this time" then click "Next".



On new windows, check "Install from a list or a specific location" then click on "Next".



To finish, check « search the best pilotes in location » and specify the location of the file « Linux_acm_inf ». This file is available with the documentation of router. Click on « Next ».



8.3 Terminal installation (Tera Term)

To view information from the USB communication, a terminal must be used. If you do not have a terminal, you can use TeraTerm available on www.occitaline.com web site. Start Tera Term. A window appears, click on "File" then "New Connection".




Figure 88
Start Tera Term configuration

Select « Serial » and in port the nom of device connected.



Under Windows 8, the device will be appear with name « ELMO GMAS »



Under Windows 7/XP, the device will be appear with name « g_serial »

The terminal configuration is made by clicking on "Settings" then "Serial Port", below the values to be set. Confirm by clicking "OK"




Figure 89
Configuration of serial port USB

END OF DOCUMENT



Centre Commercial Plein Centre
Allée du Quercy
31770 Colomiers
France
+33(0)5 34 28 12 24
support@occitaline.com